

Quick Disconnects



24A238- Female Disconnect 1/2"

(used on 2006' newer fryers)



24A239 Male Plug 1/2"

(used on 2006' newer fryers)




22677-Female Disconnect 3/8"

(used for standpipe/suction hose)



22676- Male Plug 3/8"

(used for standpipe/suction hose ends)



24246- Female Disconnect 1/2"

(used for Washwand hose ends)



24396- Male Plug 1/2"

(used for Washwand hose ends)



19248- Weldment, Wand Disconnect

22620- Knob, Ball 3/8" Blk

*not shown

24A078- Female, Disconnect 1/2" Orange Seal

(used on Washwand & Spray Blasters)

24A077- Male Plug 1/2"

(used Washwand & Spray Blasters)