


Lever Handles- Door Panel



1. Pump Activation Switch:
18A287- Switch, Toggle 120V
2. Drain Levers: (thicker left side handle)
12A105- P2 (2")
12A476- P3-14 FD (1 1/4")
12A477- P3-18/20 FD (2")
3. Wash Wand (Red) Handle:
Call UFS for more information
4. Filter Pump Lever: (thinner right side handle)
12A106- P2 (3/4")
19A615- P3-14 FD (1/2")
19A617- P3-18/20 FD (1/2")

